


Indicators Heads



Indicator Heads

| Part No. | Description | Thread | Part No. | Description | Thread |
|-------------------------------|---|--------|-------------------------------------|-----------------------------------|--------|
| Heads (require handle) | | | Heads (with built-in handle) | | |
| 54-556-108 | Handle for 8mm stem | M6 | 54-556-608 | Type A mini-indicator with shroud | M6 |
| 54-556-138 | Handle for 3/8" stem | M6 | 54-556-708 | Type C indicator with shroud | M6 |
| 54-556-117 | Handle for 8mm stem | M10 | 54-556-617 | Type A mini-indicator with shroud | M10 |
| 54-556-118 | Handle for 3/8" stem | M10 | 54-556-719 | Type C indicator with shroud | M10 |
| 54-556-622 | Type B mechanical dial gage 0.000050" (0.001mm) resolution | | Extensions | | |
| 54-556-625 | Type D Digital indicator | | 54-556-104 | 100mm extension | M6 |
| | | | 54-556-110 | 100mm extension | M10 |

Contact the Fowler Technical Department for more application concepts and accessories.

